

FREESTYLE ROCKER™

HOW TO STOP YOUR FREESTYLE ROCKER FROM SQUEAKING



If your Freestyle Rocker has begun to squeak, try one of these three methods and you'll be rocking squeak-free in no time:

Tighten these bolts.

Using silicone lubricant spray, spray around the top of the shock.

Using WD-40, spray a small amount on both sides of the frame, where the shock meets the lower foot.

TIP: You can typically find silicone lubricant spray at hardware or home improvement stores.